



Applicator Training Documentation

Coating Application: X-Protect Vinyl & Linoleum

X-Protect Vinyl & Linoleum provides a major cost savings over waxed floors (industry stated 40-60%). Saves labor and equipment costs of waxing/stripping floors on-going. X-Protect Vinyl & Linoleum is chemical and UV resistant, waterborne, low VOC and easily cleaned with hot water and safe cleaners. X-Protect Vinyl & Linoleum comes in both high-gloss and quick-dry semi-gloss finish.

BEFORE Coating

- Ensure that proper stripping, cleaning & color sealing procedures have been followed
- Make sure floor is completely moisture free (test with moisture meter: 20% or less)
- Make sure that final touches are complete with color seal (haze removed)

Tools Required For Coating VCT, Laminate/Sheet Vinyl, Luxury Vinyl & Rubber

- Roller frames
- Roller covers
- Stir Stick
- 2 Poles
- Scale
- Mixing bucket with scale on side
- Towels
- Cut-in frames
- T-bar
- T-bar cover
- Water Source

Process To Apply Coating --VCT, Laminate/Sheet Vinyl, Luxury Vinyl & Rubber

- Follow mixing instructions for the product
- After mixing you have 1 hour before the product sets up and spoils, so it must be applied efficiently
- Tape any adjacent floors on the line to create a clean edge
- Start in the back of the room and pour the product a ribbon across the floor approximately 6" from the wall
- Spread with T-Bar applicator, cut it in and then back roll with roller
- Repeat until finished with the entire floor
- Setup time for wet edge is 2 min
- Dry time is 8-12 hours
- **Note:** Dry times can vary due to humidity, venting, weather, etc
- Remove tape
- After coating, secure the room (tape off doors, put signs up, barricade, post re-entry time (12 hours for XGen Coatings)